



6



30-60SEC

7



**BOMBARDIER**

© 2021 BOMBARDIER INC.

# WATER SERVICING GUIDE



Global 5500

Global 6500

*GLOBAL 5000*

*GLOBAL 5000*

FEATURING GLOBAL VISION FLIGHT DECK


*GLOBAL 6000*

*GLOBAL EXPRESS XRS*


*GLOBAL EXPRESS*

GLOBAL\_Water\_Servicing\_Guide

This guide is intended only to assist ground personnel. Always follow the applicable instructions in the Supplemental Maintenance Manual (SMM) and obey all safety precautions when performing water servicing procedures. In the event of a conflict between the instructions in this guide and the SMM, the SMM shall take precedence over this guide.




1




Self Test  
2mins.

★ External Water Service Panel can be different than illustrated, based on aircraft model.




0°C (32°F)  
-20°C (0°F)




20mins.

2





55 PSI MAX

3



4



5

