

IP ADDRESSES (G5000 and XRS)						
	# 1	# 2	# 3	# 4	# 5	# 6
Component	<i>LH FWD</i>	<i>RH FWD</i>	<i>LH MID/AFT</i>	<i>RH MID/AFT</i>		
ZDE	10.145.8.1	10.146.8.1	10.147.8.1	10.148.8.1	10.149.8.1	
TSE 1	10.145.17.1	10.146.17.1	10.147.17.1	10.148.17.1		
TSE 2	10.145.18.1	10.146.18.1	10.147.18.1	10.148.18.1		
VEE	10.145.9.1	10.146.9.1	10.147.9.1	10.148.9.1		
DTE	10.145.10.1	10.146.10.1	10.147.10.1	10.148.10.1	10.149.10.1	10.150.10.1
CD/DVD/MP3 Players	10.145.20.1	10.146.20.1	10.147.20.1			
Monitors (note not all monitors are installed)	R Fwd Blkd Bulkhead	L Aft Blkd Monitor	LH Fwd Blkd Monitor	R Aft Blkd Monitor	R Mid-Fwd Monitor	L Mid-Fwd Monitor
	10.145.10.1	10.146.10.1	10.147.10.1	10.151.10.1	10.152.10.1	10.153.10.1
	R Mid-Aft Monitor	L Mid-Aft Monitor	Crew Area Blkd Monitor			
	10.154.10.1	10.155.10.1	10.156.10.1			
Galley TSE						
Controller	10.148.11.1					
Audio Encoder	10.148.11.2					
PME-6000 1						
MCE 1 PME	10.145.2.1					
MCE 1 MME	10.145.3.1					
MCE 1 ESE	10.145.1.1					
PME-6000 2						
MCE 2 PME		10.146.2.1				
MCE 2 MME		10.146.3.2				
MCE 2 ESE		10.146.1.1				
Print Converter	10.145.28.1					
Printer Server	10.145.25.1					
ILSD	10.145.24.1					
WLAN						
Using Laptop						
CAUTION: Ensure you are following approved procedures when connecting to the PME or MME.						
MCE 1 Connection from Pilot RJ-45 Jack	http://10.145.2.2/tse/gui.html?t=galley&p=1					
MCE 2 Connection from Co-Pilot RJ-45 Jack	http://10.146.2.2/tse/gui.html?t=galley&p=1					
MME 1 Connection from Pilot RJ-45 Jack	ftp://10.145.3.1 ftp://10.145.3.2					
MME 2 Connection for Co-Pilot RJ-45 Jack	ftp://10.146.3.2					

FOR TRAINING PURPOSES ONLY